

Product Features

- Easy to Apply
- Fast Dry
- Superior Flow-out and Leveling

- Excellent Adhesion
- Outstanding Mar and Abrasion Resistance
- Economical to use

Surface Preparation

- Wash vinyl or plastic with soap and water
- Wipe with isopropyl alcohol
- Cleanse area wiping dry with lint free towel
- Apply to light coats or until full coverage is achieved

Recommended Application

- Adjust HVLP air pressure to 30 psi at the gun
- Fluid tip 1.2 1.4 mm
- Apply two light coats
- Allow 8 10 minutes between coats

Mixing Instructions

- Single Stage
- 2K

- 2 Parts by Volume Vinyl Color
- 1 Part by Volume Fast Polyurethane Reducer
- 8 Parts by Volume Vinyl Color
- 1 Part by volume MMH-93 polyurethane catalyst Part B RTS; 2 parts Vinyl Color A+B

Dry Times @ 75°F

- Single Stage
- Dust free: 2 5 minutes
 Tack free: 10 -15 minutes
 Handle: 40 60 minutes
- 2K
- Dust free: 10 20 minutesTack free: 40 60 minutes
- Handle: 1 2 hours

Product Specifications

Viscosity

RTS: 16 - 18 sec Zahn #2

Repairability

Excellent

% Solids By Volume

18%

% Solids By Weight

34%

Pot Life:

Single Stage: N/A 2K: 2 - 3 Hours

Theoretical dry film thickness

288 sq/ ft. @ 1 mil

VOC:

Vinyl Color: V.O.C.: < 678 g/l (5.65 #/gal) RTS: V.O.C.: < 742g/l (6.18 #/gal) This product may require several components and must be mixed properly to comply with V.O.C. regulations. This product is not recommended as part of a multi-coat system if the V.O.C. exceeds local, state or federal regulations.

Technical Tips

- Water beading on surface indicates that the substrate is not thoroughly clean. Repeat isopropyl alcohol prep as needed.
- For difficult substrates:
 - o Apply a thin coat of SPC 0010 Bullfrog Adhesion Promoter
 - $\circ\quad \mbox{\rm Mix, 8 parts by volume vinyl color}$
 - 1 part by volume SPC 0010 Bullfrog Adhesion Promoter
- Carpet and Velour; Clean with appropriate carpet upholstery shampoo to remove excess soil. Allow to dry, then vacuum. Spray one light mist coat of color and allow a 5 minute flash time, then follow by brushing. Apply a second light mist coat and brush again. Use sparingly on carpet and velour as not to change the texture or feel of the surface being sprayed.
- Texture finishes; spray to achieve full coverage. Let the panel flash 3-7 minutes, drop the gun air pressure to 1 3 psi then spray to achieve desired texture.

Product Safety Data

• Consult safety data sheet (SDS)